





PU-AMI Sealing-off Kit

Items	Explanations	Pictures
<i>Fabric wire mesh + transparent plastic sheet + timber frames</i>	<p>To seal off the windows, to prevent water, wind and dust going through broken window.</p>	
	<p>How to use:</p> <ol style="list-style-type: none"> 1) Put the wire mesh/transparent sheet over the window to transfer the size of the window to the wire mesh/ transparent sheet. 	
	<ol style="list-style-type: none"> 2) Use the cutter to cut the wire mesh/ transparent sheet. Make sure you add 10 cm extra from each side (e.g. if the window is 100cm*100cm cut them 120cm*120cm) 	
	<ol style="list-style-type: none"> 3) Put the wire mesh/ transparent sheet over the window then put the timber frames around the window. 4) Use the nails and the hammer to fix the timbers over the wire mesh/ transparent sheet. 	 

To fill the gap in glass, aluminum, concrete surface and wood.

How to use:

- 1) Firstly, clean the surface you want to fix and remove any dust.



- 2) Then, open the tube using the cutter.



- 3) Cut the silicone Tube's nozzle with 45 degrees using the cutter.



- 4) Put the silicon tube in the silicon gun.



- 5) Point the nozzle in the place you want to fill and start pressing the handle.




**Silicon +
acrylic tubes**

***Plastic rubber
for doors /
windows***

To fill the gaps between the door or window and the frames. To prevent wind, water leakage or dust going through windows or doors.

How to use:

- 1) Separate the adhesive plastic rubber from its cover part.
- 2) Stick the adhesive part to the door/window.
- 3) Make sure the rubber is completely attached to the door / window.



***Painting paste
– 5kg canister***

To fill up the small cracks or gaps. To stop water leakage and humidity by adding another layer to the walls/ceiling

How to use:

- 1) Firstly, clean the surface you want to fix from all dirty stains.
- 2) Then, use the scraper to fill the cracks/gaps with the paste and repeat back and forth on the gaps to make sure it is properly filled.
- 3) Finally, wait for the wall to completely dry, for at least 2 hours.



Moisture proof painting

Give the wall/ceiling a higher resistance against rot, humidity and fungus

How to use:

- 1) First, clean the surface you want to fix from all rot and leakage residue by using water or any cleaning product.



- 2) Use the sand paper to scratch walls/ceiling and make the surface smoother.



- 3) Cover all the edges you do not want to paint (e.g. doors edges) using the tape.



- 4) Mix each 3.6 Liter paint canister with 1 liter of water and keep mixing until it becomes homogeneous.



***Plastic sheet
(heavy duty)
orange***

To seal off the ceiling and prevent water leakage, wind, dust and insects passing through.

How to use:

- 1) Put the plastic sheet over the ceiling/roof you want to cover.
- 2) Use the cutter to cut the plastic sheet and make sure you cut extra length from each side. For example if the ceiling is 3m * 3m, cut 3.25m * 3.25 m.
- 3) Use the nails and the hammer to fix the sheet to the edges.



To seal off the floor and prevent heat transfer.

How to use:

- 1) Firstly, clean the floor with water or any cleaning product.
- 2) Secondly, use the cutter to cut the under layer and the carpet to exactly the same size of the soil you want to cover.
- 3) Then, put the under layer over the floor.
- 4) Use the silicon tube to attach the under layer to the floor. Use the silicon only in the corners.
- 5) Make sure there is no gaps between the under layer and the floor.
- 6) Finally, put the carpet over the under layer and attach it thanks to the silicon.



Carpet + under layer

Fabric

To seal off window/doors for better insulation and to provide privacy.

How to use:

- 1) Use the cutter to cut the fabric the size you want.
- 2) Attach the polyester rope with the piece of fabric.
- 3) Attach the rope to the wall by using the nails and the hammer.

